

SECURE USB

BLUETOOTH®

SecureUSB® BT Quick Start Guide

SECUREUSB® BT

Welcome to the SecureUSB BT Model, our app-controlled hardware encrypted USB flash drive that is OS-independent and controlled via smartphone (iOS, Android).



SecureData Lock

INSTALLING THE APP

Download and install the **SecureData Lock App** from either Apple's App Store or Google Play.



CAUTION: Risk of data loss. If you forget your password, all data will be inaccessible and reformatting will be required.

LED INDICATORS

LEDs on the SecureUSB are represented below by colored icons.

| | | |
|--|--|--|
| | Red LED is solid | USB is locked, or may indicate procedure failed |
| | Red LED is blinking | Locked, recognized by mobile device |
| | Blue LED | Drive is unlocked; transferring data if blinking |
| | Represents the LED on the USB | |
| | Represents the icon in the App: Green = success or unlocked Red = failed or locked | |

ADDING THE USB BT TO THE APP (PAIRING)

1. Plug in the USB and then start the app.
2. Tap the USB name and follow the on-screen instructions.

UNLOCKING THE USB

CAUTION: Possible loss of data, settings, and password. After 10 consecutive failed attempts to unlock, the USB flash drive will be erased (reset). Refer to *Brute Force Hacking* in the User Manual.

1. With the app running and after tapping the USB name
2. Enter the password (factory default 11223344)
3. Tap Unlock

NOTE: For security, we strongly suggest changing the factory password to a new password.

CHANGING THE PASSWORD

PASSWORD REQUIREMENTS: 7-15 digits, special characters are okay. Cannot all be the same number/letters nor consecutive numbers/letters. (4444) (1234)

1. Unlock the drive in the app.
2. Tap the desired USB name.
3. Tap **Change Password** and enter your current password.
4. Enter new password and then retype it into the **Confirm** field.
5. Tap **Change Password**.

DISCONNECTING AND LOCKING

Unplug the USB-BT — the drive locks automatically. Generally, ejecting the USB first is not necessary, but preferable. To lock the USB without unplugging it, swipe left on the USB name on your phone and tap **Lock**.



MORE ONLINE

For more features and for troubleshooting, see the SecureUSB BT Model User Manual on our website: <https://www.securedrive.com/documents/user-manual-secureusb-bt.pdf>



REGISTER YOUR DEVICE

To register your drive on your SecureData account, go to <https://www.securedrive.com/register>